


MICROFIBER


Used for casual wear, sports wear, pants and jackets.
NO STRETCH!

As the colours may vary, depending on screen resolution
colour charts are only meant as a guideline.

1128-1000



1128-1060




1128-2002



1128-3010



1128-3097



1128-5017



1128-5051



1128-5081



1128-5097




1128-7017



1128-7097



1128-8027



1128-8035



1128-9025

