



WASHING - DRYER MACHINE


Product parts




A × 1pc



B × 1pc




C × 1pc




D × 1pc




E × 1pc




F × 1pc




G × 1pc




H × 1pc



I × 1pc



J × 1pc



K × 1pc




L × 1pc



a × 24pcs


Required Tool (not included)




Screwdriver

Steps


1




2





3



4




5**6**

WARNING:
 CHOKING HAZARD-Small parts. Not for children under 3 years.
 Adult assembly is required.
 Remove all the packaging and attachments before giving the toy to a child.
 Please retain this packaging for future information.

ADVARSEL:
 KVÆLNINGSRISIKO - indeholder små dele. Ikke egnet til børn under 3 år.
 Montering skal udføres af en voksen.
 Fjern venligst al emballage og fæstning inden legetøjet gives til barnet.
 Gem venligst emballagen for fremtidig information.

WARNING:
 KVÄVNINGSRISK - Innehåller smådelar. Ej för barn under 3 år.
 Produkten måste monteras av en vuxen.
 Allt förpackningsmaterial ska avlägsnas innan leksaken ges till barnet.
 Vänligen spara all information för framtida referens.

ACHTUNG:
 ERSTICKUNGSGEFAHR - Kleinteile. Nicht geeignet für Kinder unter drei Jahren.
 Montage durch einen Erwachsenen erforderlich.
 Bevor Sie den Artikel ihrem Kind geben entfernen Sie bitte Verpackung sowie Befestigungen.
 Bitte die Packung für zukünftige Information aufbewahren.



Art.No. 83522

Made in China