

## DIPSWITCH SETTING CBHD3 36/48V - 5A/10A

**DIPSWITCH:**

SW1		
DP1	DP2	
ON	ON	Index 3 IU00-EV AGM DISCO
ON	OFF	Index 0 IU0a Wet
OFF	ON	Index 2 IU0U AGM FULLRIVER
OFF	OFF	Index 1 IU0a GEL EXIDE

	SW2	
	DP1	DP2
ON	10 A	36V
OFF	5 A	48V

Dipswitches are located behind the white label on the top side of the charger and next to the green led you will find 2 sets of dipswitches (SW1 and SW2).

Only the set of dipswitch SW1 (the one on the left side) has effect on charging curve selection accordingly to the table above.

Once you have finished to configure the charger with the desired charging curve according to the battery pack type you have installed in the machine, please cover again the dipswitches with the white label you have previously removed.